

INSTALLATIONADVICE.COM

SOLUTIONS & TOOLS FOR PROBLEMS THAT MAY ARISE

END CAP (ME) - ENGINEERED WATERPROOF FLOORING - SPECIAL ORDER

Technical Information - Sizes


End Cap (Square Nose)

End Caps are used to transition from engineered waterproof flooring to carpet, masonry (fireplaces), sliding doors and other exterior door jambs.

Surface Material: High Wear Resistant Aluminum Oxide Laminate

Core Material:


Moisture Resistant End Cap: Exterior Grade Composite Wood Product



Versatrack

To be used with T-Molding, Reducer and End Cap for floors from 6mm - 9.5mm thickness.


Material: Cold Roll Steel



Installation

6 - 9 mm Floors

Use Versatrack (Metal Track) for 6 - 9.5 mm floors.



INSTALLATIONADVICE.COM


SOLUTIONS & TOOLS FOR PROBLEMS THAT MAY ARISE

END CAP (ME) - ENGINEERED WATERPROOF FLOORING - SPECIAL ORDER

Use Versatrack (Metal Track) for 6 - 9 mm floors




6 - 9 mm Floors




Step 1

Install the flooring planks by leaving a 1-1/8" inch (28mm) gap for the installation of the End Cap molding.



Step 2

Center the U-Track between the carpet and the engineered waterproof floor and screw it to the sub-floor by using #6x5/8" screws.



Step 3

Gently press the molding into the track starting from one end to the other just like you would close a Zip-Lock bag.

!!! Do not try to push the entire molding in all at once by just pressing it in from top !!!

