

INSTALLATIONADVICE.COM SOLUTIONS & TOOLS FOR PROBLEMS THAT MAY ARISE

T-MOLDING (MM) FOR ENGINEERED WATERPROOF FLOORING - SPECIAL ORDER

Technical Information - Sizes


T-Molding

T-Moldings are commonly used in doorways to join two floors in adjoining rooms. Also recommended when making a transition from floor to another floor that is approximately the same height.

Surface Material: High Wear Resistant Aluminum Oxide Laminate

Core Material:


Moisture Resistant T-Molding: Exterior Grade Composite Wood Product



Versatrack

To be used with T-Molding, Reducer and End Cap for floors from 6mm - 9.5mm thickness.


Material: Cold Roll Steel



Installation

6 - 9 mm Floors


Use Versatrack (Metal Track) for 6 - 9.5 mm floors.




INSTALLATIONADVICE.COM SOLUTIONS & TOOLS FOR PROBLEMS THAT MAY ARISE

T-MOLDING (MM) FOR ENGINEERED WATERPROOF FLOORING - SPECIAL ORDER

Use Versatrack (Metal Track) for 6 - 9 mm floors




6 - 9 mm Floors




Step 1

Install the flooring planks including the underlayment by leaving a 1" inch (25mm) gap for the installation of the T-molding.



Step 2

Center the U-Track between the two floors and screw it to the sub floor by using #6x5/8" screws.



Step 3

Gently press the molding into the track starting from one end to the other just like you would close a Zip-Lock bag.

!!! Do not try to push the entire molding in all at once by just pressing it in from top !!!

